

ULTRASONIC A

CONCENTRATED DEGREASER

ULTRASONIC A is formulated with diluents, nonionic and anionic surfactants to be used as a degreaser additive with alkaline products in degreasing and phosphating processes in ultrasound machine. With its balanced formulation exhibits excellent wetting action.

DOSAGE AND METHOD OF USE

This product may be used diluted in the water tank ultrasounds at 0.5% in combination with ULTRASONIC 7 (this at a ratio of 3%)

TECHNICAL SPECIFICATIONS

COLOR: YELLOW

ASPECT: TRANSPARENT LIQUID

SMELL: CHARACTERISTICS

DENSITY: 1,01 +/- 0,05 g/cm³

PH 1%: 7,5 +/- 0,5

CONTAINS AMONG OTHER COMPONENTS

< 5% Glycols

>30% Non ionic surfactants

This product meets the existing legislation on biodegradability and the Sanitary Technical Regulation on Detergents.